## ACCESSORIES

| | |
|---|---|
| Blade wrench | 1 pc |
| Work clamp | 1 pc |
| Miter lock handle | 1 pc |
| Dust bag | 1 pc |
| Extension rails | 1 set |
| 10"x40T carbide tipped saw blade | 1 pc |

We recommend that you purchase your accessories from the same store that sold you the tool. Use good quality accessories with a well-known brand name. Choose the type according to the work you intend to undertake. Refer to the accessory packaging for further details. Store personnel can assist you and offer advice.

## SAFETY INSTRUCTIONS

⚠ WARNING! READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS

1.WORK AREA

- KEEP YOUR WORK AREA CLEAN AND WELL LIT. Cluttered benches and dark areas invite accidents.
- DO NOT OPERATE POWER TOOLS IN EXPLOSIVE ATMOSPHERES, SUCH AS IN THE PRESENCE OF FLAMMABLE LIQUIDS, GASES OR DUSTS. Power tools create sparks which may ignite the dust or fumes.
- KEEP BY-STANDERS, CHILDREN, AND VISITORS AWAY WHILE OPERATING A POWER TOOL. Distractions can cause you to lose control.
- MAKE WORKSHOP CHILD PROOF with padlocks, master switches, or by removing starter keys.
- NEVER LEAVE THE TOOL RUNNING UNATTENDED. Turn power off. Do not leave the tool until it comes to a complete stop.
- STORE IDLE TOOLS. When not in use, store your tool in a dry, secured place. Keep out of reach of children.

2.ELECTRICAL SAFETY

- DOUBLE INSULATED TOOLS ARE EQUIPPED WITH A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN TO INSTALL A POLARIZED OUTLET. DO NOT CHANGE THE PLUG IN ANY WAY. Double insulation eliminates the need for the three wire grounded power cord and grounded power supply system. Before plugging in the tool, be certain the outlet voltage supplied is within the voltage marked on the nameplate. Do not use "AC only" rated tools with a DC power supply.
- AVOID BODY CONTACT WITH GROUNDED SURFACES SUCH AS PIPES, RADIATORS, RANGES AND REFRIGERATORS. There is an increased risk of electric shock if your body is grounded. If operating the power tool in damp locations is unavoidable, a ground fault circuit interrupter must be used to supply the power to your tool. Electrician's rubber gloves and footwear will further enhance your personal safety.
- DON'T EXPOSE POWER TOOLS TO RAIN OR WET CONDITIONS. Water entering a power tool will increase the risk of electric shock.
- DO NOT ABUSE THE CORD. NEVER USE THE CORD TO CARRY THE TOOLS OR PULL THE PLUG FROM AN OUTLET. KEEP CORD AWAY FROM HEAT, OIL, SHARP EDGES OR MOVING PARTS. REPLACE DAMAGED CORDS IMMEDIATELY. Damaged cords increase the risk of electric shock.
- WHEN OPERATING A POWER TOOL OUTSIDE, USE AN OUTDOOR EXTENSION CORD MARKED "W-A" OR "W". These cords are rated for outdoor use and reduce the risk of electric shock.
- GROUNDED TOOLS MUST BE PLUGGED INTO AN OUTLET PROPERLY INSTALLED AND GROUNDED IN ACCORDANCE WITH ALL CODES AND ORDINANCES. Never remove the grounding prong or modify the plug in any way. Do not use any adapter plugs. Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded. If the tool should electrically malfunction or break down, grounding provides a low resistance path to carry electricity away from the user.

3.PERSONAL SAFETY

- STAY ALERT, WATCH WHAT YOU ARE DOING AND USE COMMON SENSE WHEN OPERATING A POWER TOOL. DO NOT USE TOOL WHILE TIRED OR UNDER THE INFLUENCE OF DRUGS, ALCOHOL, OR MEDICATION. A moment of inattention while operating power tools may result in serious personal injury.
- DRESS PROPERLY. DO NOT WEAR LOOSE CLOTHING OR JEWELRY. CONTAIN LONG HAIR. KEEP YOUR HAIR, CLOTHING, AND GLOVES AWAY FROM MOVING PARTS.



RK7135 psm254mu 060602.indd 6 2006-7-19 17:15:37